

Specification of state independent actions. If the Required Pressure value changes:

- the Error Counter is reset,
- the Pressure Limits are recalculated,
- the Pressure value is set.

Always	RequiredPress_CHANGED	Counter_ResetStart Ofun_CalcLimit SetPressure_Set
--------	-----------------------	---